

MODEL 610A

Four-Channel Combustible Gas Monitor



Features

- Four Independent Channels
- Low power consumption
- High visibility LED status indicators
- Variety of relay options
- Adjustment-free calibration
- Low cable costs

Benefits

- Maximum reliability
- Low operating costs
- Provides visual indication of fault and alarm status at the detector location
- Provides choice to meet specific customer requirements
- Lower calibration costs
- Lower installation costs

Description

The Model 610A Controller is a four-channel system designed to continuously monitor for potential explosive concentrations of most combustible gases/vapors. The system operates in the range of 0-100% LEL (Lower Explosive Limit) and is calibrated for a particular gas or vapor.

The system consists of four remote sensing assemblies and a solid-state controller. The controller consists of four independent channels, each having its own control circuitry. The sensors are monitored independently (i.e. they are not scanned, nor are the signals summed).

The 610A features a digital display of gas concentrations in % LEL (0-99%) for each channel. Calibration of each channel is done independently with alarm relays disabled while in this mode. Normally, only a periodic calibration check is needed to assure dependable performance.

The 610A has a variety of relay options, such as normally energized or de-energized high and low alarms and latching or non-latching high and low alarms. The malfunction relay circuitry is normally energized. These relays may be discrete for each channel or common to all channels. Also included as an option is independent low and high alarm settings for each channel.

Applications

- Compressor Stations
- Drilling and Production Platforms
- Fuel Loading Facilities
- Gas Turbine Enclosures
- LNG Processing and Storage
- Oil Well Logging
- Sewage Plants
- Solvent Vapors



MODEL 610A

System Specifications

Digital Readout:	0-99% LEL
Accuracy:	±3% LEL ≤ 50% LEL gas 5% LEL > 50% LEL gas
Classification:	General purpose for mounting in non-hazardous areas, indoors.
Warranty:	Two years
Approvals:	CSA, FM, CE Mark

Environmental Specifications

Temperature Range:	32°F to 140°F (0°C to 60°C)
Storage Temperature:	-4°F to 149°F (-20°C to 65°C)
Humidity:	10-95%, non-condensing

Mechanical Specifications

Mounting:	Panel or wall
Dimensions:	4.0" W x 6.9" H x 11.5" D (102mmW x 175mmH x 292mmD)
Weight:	6.2 lbs. (2.86 kg)

Electrical Specifications

Power:	105-130 VAC (205-255 VAC optional), 50-60 Hz, 22-30 VDC, 9 watts nominal per channel (117 VAC)
Output:	Analog 4-20mA (300 ohm load max.) Accuracy ±5%, 1.5-20mA
Alarm Circuits:	4A/117 VAC, resistive
LED Status Indicators:	AO - Analog output malfunction SE - Sensor malfunction HI - High line voltage LO - Low line voltage
Standard Configuration:	610A-1-1-1-01-1-2-4 (110 VAC / 24 VDC, common relays/alarms, latch alarm, non-latch warn, de-energized, standard sensor, FM, Zone Controller Off, 4-Channels Active)

Sensor Elements

General Monitors' catalytic bead sensors are designed for reliable performance and long life. Each sensor must undergo extensive burn-in and rigid quality control procedures before shipment.

The sensors consist of two catalytic bead elements in a balanced Wheatstone bridge circuit. These low temperature catalytic bead sensing elements require minimal sensor excitation current, greatly increasing sensor life.

Sensor Specifications

Type:	Continuous diffusion, low temperature catalytic bead. Standard Industrial Hydrocarbon Sensor. High Temperature Standard Industrial Hydrocarbon Sensor.
Temperature Range:	-40°F to +167°F (-40°C to +75°C) High Temperature Sensor to 392°F (200°C)
Response Time:	T ₅₀ : typically 6 seconds
Zero Drift:	Less than 5% per year
Life:	3 to 4 years, normal service
Classification:	Class I, Division 1 and 2, Groups B, C and D


Cable Length: Three conductor cable. Maximum length of cable between controller and sensor assembly with loop resistance of 20 ohms NOTE: Shielded cable is recommended

Wire Size	Length	
	(Meters)	(Feet)
14	2,320	7,600
16	1,460	4,800
18	910	3,000
20	580	1,900

Warranty:	Two years
Approvals:	CSA and/or FM

Specifications subject to change without notice.

Represented by:



Equipamientos Analíticos S.A

DESDE 1989 | BRINDANDO SOLUCIONES