



InteliHeat® Thermulate® Gas Bottle Heating Jacket (HHG)

Our InteliHeat® Thermulate® HHG Gas Bottle Heating Jacket for non-hazardous ordinary locations provides a boost in power for applications/materials needing a fast heat-rate up to approximately 140-158°F (60-70°C).

- Fitted with 32-194°F(0-90°C) adjustable thermostat.
- Black polyester fabric outer layer, high-temperature silicone-coated glass-cloth inner layer.
- High grade thermal insulation to reduce heat loss and increase efficiency while providing protection for the operator.
- Fitted with adjustable retaining straps and quick release buckles.
- Flexible - conforms to the container wall providing optimal thermal coupling
- Delivers heat over a large surface area, minimizing the possibilities of damaging the product.
- Fit and forget, built to last - no regular maintenance required.
- Safe to use 24/7.
- 7 ft. (2m) premium oil, water, and abrasion resistant power cable
- Ambient temperature: -40°F to +104°F (-40°C to +40°C)
- Waterproof and custom sizes available.

To fit container: Gallon / Fits size A, K, 150A, 200, 300, 75lb Liter

Thermostat: Adjustable 0-90°C / 0-194°F

Size: Circumference 27" – 32.5" / Height 48" (685 – 830mm / 1210mm)

Includes 6" / 150mm adjustable collar at top of jacket

240 Volts

800 Watts

Part Number: HHG24090

